



LIABILITY WAIVER

By purchasing the Sui Generis Seat (“the Product”), you agree that you have read, understood and meet all applicable Safety Disclosures and Rider Requirements for the Product and have reviewed the safety guidelines published by Segway Inc. for the Segway Personal Transporter. You operate the Segway® PT and the Product at your own risk and understand that Georgios Sinanis (“the Seller”) cannot be held liable for any injuries, accidents or damages resulting from use.

The Product is not an approved medical or mobility device by any regulatory agency. Although it can facilitate mobility for people of varying abilities, if not used with caution it can cause injury and even possible death. Users assume all liability for damages, injuries and loss and cannot hold the Seller or Segway Inc. liable for any accidents resulting in the use of the Segway® Personal Transporter and/or the Product. Since the Product is just an attachment to the Segway® PT, it is recommended that you read and follow all of the safety procedures and recommendations issued by Segway Inc. for operation at the website <http://www.segwaysafety.com> in addition to the following guidelines. The Seller cannot be held responsible for any damage to the Segway® PT due to incorrect installation or operation of the Product.

Safety Disclosures

It is the responsibility of the consumer to be sure s/he reads and understands all the risks of riding before they purchase or attempt to ride the Sui Generis Seat.

Riding the Segway® PT with or without the Sui Generis Seat risks serious injury or death from falls, loss of traction, loss of balance, collisions and other accidents.

- To reduce the risk of injury, read the Segway® PT manual and the Sui Generis Seat manual to learn safe mount, dismount and riding procedures.
- Follow all safety guidelines for riding the Segway® PT and the Sui Generis Seat.
- In case of an Emergency Shut-Down, the Segway® PT falls over. The Sui Generis Seat will only prevent this if the parking stand (if included) is deployed as defined in the user's manual.
- The parking stand should only be deployed and retracted on solid, level surfaces.
- The parking stand should not be deployed while moving.
- Only mount or dismount the Sui Generis Seat with the parking stand properly deployed and with the Segway® PT on “alarm” mode.
- Always wear a helmet when riding the Sui Generis Seat.
- Always be aware of your surroundings and any obstacles in your path. Stay clear of any holes or drop offs.
- Do not ride the Sui Generis Seat in the dark; on loose gravel; in high winds; on ice, snow, or slush; in wet or slippery conditions.
- Steer clear of any obstacles that may obstruct one of the wheels and cause the Segway® PT to fall over.
- The rider should always carry the Infokey of the Segway® PT while using the Sui Generis Seat. Operating the Segway® PT without the rider carrying the Infokey may cause the Segway® PT to switch off unexpectedly.
- Be aware of the charge status of the battery. Do not attempt to ride when the battery indicator on the Segway® PT Infokey is at or less than one bar.
- Keep obstructions such as straps, clothing, jewellery, and bags away from the wheels and other

- moving parts.
- Provide ample space to allow for a safe stop, as the Sui Generis Segway Seat coasts to stop.

Rider Requirements

- Rider is able to mount and dismount the Sui Generis Seat.
- Rider is able to adjust his/her position in the Sui Generis Seat without assistance.
- Rider has the core strength to stay in the Sui Generis Seat by holding his/her position on it.
- Rider is physically able to lean forwards and backwards in swift movements.
- Rider is not prone to dizziness, fainting or suffering from any condition that may lead to loss of consciousness.
- Rider does not suffer from regular leg or back spasms.
- Rider does not have vision problems which would impair his/her ability to operate the Sui Generis Seat.
- Rider can deploy and retract the stabilizers in one, swift motion with one hand while steadying himself/herself on a separate solid surface with the other. Approximately 5.6 kilograms of push and 3.1 kilograms of pull are required to operate the parking stand lever.
- Rider can operate the steering lever. Approximately 1.5 kilograms of pull and push is required to operate the steering lever.
- Rider can deal with an Emergency Shutdown. An Emergency Shutdown provides rider with approximately 10 seconds to get off the Sui Generis Seat or deploy the parking stand before it falls over.
- Rider possesses reasonable mental aptitude to apply sound judgement while operating the Sui Generis Seat.
- Rider is over 18 years old; or, if under 18 years old, has his/her parents' or guardians' permission to ride the Sui Generis Seat.
- Rider weighs at least 40 kilograms and not more than 98 kilograms.
- Rider is physically able to survive falls.